
PCT-30 ADW-D

Introduction: The PCT-30-ADW-D has the same operation principals as the PCT's that have been designed for smaller cylinders, therefore, these instructions have been written in addendum to the standard PCT-ADW-D instruction manual (part number 21-11-1009).

Safety:

1. When loading or unloading cylinders into the cradle area of the PCT, ALWAYS use a fork lift or hoisting mechanism.
2. After loading the cylinder, ALWAYS be certain the safety chain is clipped and in place around the cylinder.
3. Once the cylinder has been loaded and clamped, be certain to stay behind the control panel to avoid the range of the cylinder rotation and the possibility of being splashed with hot water.
4. Be certain to stay clear of the Clamp Arms after the clamp cylinder button has been pressed and anytime that the PCT30-ADW-D is in motion.

Start Up:

- A. Load the cylinder into the cradle and insert the Air Injection Tube into the neck of the cylinder. Connect the base of the Air Injection Tube to the Injection Quick Connect, located on the Cylinder Clamp Arm.
- B. Make sure to place the Safety Chain around the cylinder and that the clip is securely attached.
- C. Turn the power switch to the ON position.
- D. Keeping hands, hair, and any loose clothing clear of the Clamp Arms as the clamping motion begins.
- E. After the cylinder has been loaded and clamped, press Manual or Auto on the control panel. For complete operation instructions, refer to PCT-ADW-D instruction manual part number: 21-11-1009.